

DIGITAL TAP-TIMER 2 STATIONS (DT-S)

GENERAL FEATURES

1. Two-station controller
2. Working voltage: 2X1,5Volt (2 alkaline batteries AA)
3. Connection: 1 Input - 2 output 3/4" Female -Male threaded (Sealing gasket included)
4. LCD screen
5. Electrovalve with NBR membrane and latching solenoid.
6. Five ergonomic knobs for easy programming.
7. Knob for manual operation
8. Maximum operating pressure 6 Atm at 20°C

SPECIFICATIONS

Irrigation time: from 1min to 6 hours.

Irrigation frequency: every 6 or 12 hours or 1 - 2 - 3 - 4 - 5 - 6 or 7 days

Time delay: 24, 48 or 72 hours

DIMENSIONS

Width: 15cm / Height: 18 cm

INSTRUCTIONS

Insert 2 alkaline batteries AA in the special case at the back of the controller.

SET CLOCK

Turn the knob to "SET CLOCK" position. Screen will show the hour, the minutes and to the right AM or PM. Press (+) or (-) buttons to adjust to current time.

SET WATERING START TIME

Turn the knob to "START TIME" position, press (+) or (-) to select the desirable start watering time. Before settings, press (L/R) button for choice electrovalve "L / R" = LEFT or RIGHT.

SET WATERING RUN TIME (How long)

Turn the knob to "HOW LONG" position, press (+) or (-) to choose from 1 minute to 6 hours. Before settings, press (L/R) button for choice electrovalve "L / R" = LEFT or RIGHT.

SET WATERING FREQUENCY (How often)

Turn the knob to "HOW OFTEN" position, press (+) or (-) to choose one of the preset options that already exist: 6 - 12 hours or 1 - 2 - 3 - 4 - 5 - 6 or 7 days. Before settings, press (L/R) button for choice electrovalve "L / R", LEFT or RIGHT.

TIME DELAY

You can delay your watering start time using the Time Delay Feature. Setting the knob to the AUTO position pressing (+) will cause 24hour delay of the programmed start time. The options for delay times are: 24 hours, 48 hours or 72 hours. Change the delay time by pressing (+) or (-) at any time. Reduce to zero to cancel delay. The screen will flash between clock and hours remaining before programmed AUTO cycle resumes. Before settings, press (L/R) button for choice electrovalve "L / R", LEFT or RIGHT. To remove the watering delay, turn the knob to OFF position and then back to AUTO. The time delay applies to two electrovalves.

MANUAL OPERATION

To water without interrupting the set automatic cycle, knob must be in the "AUTO" position. Press the button marked with "Tap" symbol and 10mins is shown as a default time. Use the buttons (+) or (-) to set desirable watering time from 1 minute to 360 minutes. Before settings, press (L/R) button for choice electrovalve "L / R", LEFT or RIGHT. To stop manual watering set knob to "OFF" position.

TURNING OFF THE CONTROLLER

In order to switch off the operation of the controller set the knob to "OFF" position.

- To resume programmed cycle, set knob back to "AUTO" position.

- When controller is running a watering program, droplets will appear at the left and upper corner of the screen.

WARNING

Protect the controller from frost.

The controller is for out-door use only.

The controller is water-resistant but NOT water-proof

WARRANTY - (PURCHASE DOCUMENT VERIFICATION REQUIRED)

One (1) year warranty.

Warranty is invalid if the instructions as detailed above are not adhered to and/or the programmer has been damaged or misused due to incorrect installation.